



Life's a Beach

Design courtesy of Bisque Imports

Keep your cool with this beachy design. With minimal cutting required, glass artists of all ages will love creating this summertime treasure.

MATERIALS

BC110.2 Pale Amber Transparent Buffalo Chips
BC210.72 Almond Opalescent Buffalo Chips
CF110.2C Pale Amber Transparent Frit - Coarse
CF210.71M Ivory Opalescent Frit - Medium
CF230.72C Medium Blue Opalescent Frit - Coarse
CF533.1M Sky Blue Transparent Frit - Medium
GBLOCK267-72 Sunflower Opalescent Block
GBS8-100 8 In. Square Clear Transparent
GSLAB60-726 Apple Jade Slab Opalescent
GSTRIP200 White Opalescent Strip
SP-8234 Glas Tac
ST340 1" Running Pliers
ST342 3/8" Breaker/Grozer
ST352 Pistol Grip Glass Cutter
ST356 Wheel Mosaic Cutter
ST540 Thinfire Paper

SUPPLIES

Black Permanent Marker
Nipping Basket
Non-Aerosol Hairspray
Plastic Spoon
Small Paintbrush

INSTRUCTIONS

1. On the Apple Jade Opalescent Slab, use a black permanent marker to sketch two flipflop sandal shapes. Use a Pistol Grip Glass Cutter to score around each each shape. Break along each score with the Running Pliers. See provided template. Position onto the glass.
2. Sketch out each sandal strap on the Sunflower Opalescent block. Score and break each strap shape, then position onto each sandal.
3. Use the Wheel Mosaic Cutter to nip the White Opalescent Strip into small triangles. Position the triangles in scattered spots on each sandal. Apply pinpoint of Glas Tac to adhere all pieces to glass.
4. Fill the lower half of glass with Almond Opalescent Buffalo Chips. Overlay with scattered Pale Amber Transparent Buffalo Chips and coarse Pale Amber Transparent Frit. Adhere with Glas Tac.
5. Fill the upper half of background with coarse Medium Blue Opalescent frit using a spoon to dispense. Overlay with medium Sky Blue Transparent Frit in scattered areas.
6. Lightly add medium Ivory Opalescent frit in scattered areas of upper background, and generously across the center of background, where sand meets water.
7. Use a small paintbrush to clear off any frit on each sandal surface. Lightly spritz the project with hairspray.
8. Allow project to dry. Contour fuse using the Spectrum 6 segment firing.

