

FBPROK

Professional Kicking Cage ASSEMBLY INSTRUCTIONS

BOX CONTENTS

Description	Quantity
· Hardware bag	1 each
#1 Piece	1 each
#2 Piece	1 each
#3 Piece	2 each
#4 Piece	2 each
#5 Piece	1 each
#6 Piece	1 each

HARDWARE BAG CONTENTS

Description	Quantity
Eyebolts + nuts	2 each
Bungee with S-hook	1 each
Tightening Knob	2 each
Plastic Cap (50 mm)	2 each
Plastic Cap (38 mm)	2 each
Snap Pins	4 each
Carrying Bag	1 each



STEP 1

Unwrap and lay out all parts to for easy identification.

STEP 2

Insert plastic caps in the open ends of pieces 1,2,5, & 6.

STEP 3

Referring to diagram begin by attaching lower pieces #1 & #2 together as shown using snap pin attachment. Loosen tightening knobs on small upright pieces.

STEP 4

Insert Both #3 pieces into upright lower tube and hand tighten knob to secure upright #3 pieces.

STEP 5

Attach both #4 pieces as shown in diagram to both #3 pieces using snap pin attachment. Refer to diagram for proper angle of the pieces.

STEP 6

Attach #5 piece to #6 piece using snap pin attachment and then attach to top of frame as shown in diagram. Use eyebolts and nuts provided. Be sure that the eye bolt is on the inside of the frame and the nuts on the outside of the frame.

STEP 7

Layout net on the ground to determine top and sides.

STEP 8

Attach Net using Velcro wrap attachment sewn on edge of the net by wrapping around each side and top pole and securing the Velcro. Once net is installed, using provided bungee cord, pull net back at the top and attach bungee cord between the two inner eyebolts to hold the net back.

ASSEMBLED FBPROK

