

MOOER

EXPLINE

Mini Expression Pedal

Owner's Manual

Precautions

Please Read Carefully Before Proceeding

Power Supply

Please connect the designated AC adapter to an AC outlet of the correct voltage. Please be sure to use only an AC adapter which supplies 9V DC($\pm 10\%$), $\oplus - \ominus - \ominus$, center negative. Unplug the AC power adapter when not in use or during electrical storms.

Connections

Always turn off the power of this and all other equipment before connecting or disconnecting, this will help prevent malfunction and / or damage to other devices. Also make sure to disconnect all connection cables and the power cord before moving this unit.

Cleaning

Clean only with a soft, dry cloth. If necessary, slightly moisten the cloth. Do not use abrasive cleanser, cleaning alcohol, paint thinners, wax, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

Interference with other electrical devices

Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

Location

To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions:

- Direct sunlight
- Excessive dusty or dirty location
- Magnetic fields
- Extreme temperature or humidity
- Heat sources
- High humidity or moisture
- Strong vibrations or shocks


FCC certification

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:


- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Product description

EXPLINE is a micro sized expression pedal which houses high quality electrical components, ensuring smooth a precise control at all times.



Pedal layout



1.LED

Will illuminate to show that the EXPLINE has power

2.OUTPUT 1

Connect a 1/4" TRS stereo cable to the device you wish to control

3.OUTPUT 2 (Reverse)

Connect a 1/4" TRS stereo cable to the device you wish to control This output has reverse wiring from OUTPUT 1

4.DC IN


Connect to a 9V DC centre pin negative power source (EXPLINE requires power to function correctly)

5.PEDAL EXTENSION RINGS


Extend to increase the pedestal surface area for increased comfort

Setup Instruction

Note: Output 1 and Output 2 are wired differently from one and other to ensure good operation with equipment from many different brands. Try both outputs to find which renders the best results



(TRS)



(RTS)

Specifications

Power: 9V DC centre pin negative. $\oplus \ominus \ominus$

Recommend Mooer Micro Power

Power consumption: 35mA

Dimensions: 128mm(D) x 55mm(W) x 48mm(H)

Weight: 460g

Accessories: Owner's Manual

**Notes: Any specification's update will not be amended in this manual.*

MOOER

MOOER AUDIO CO.,LTD
www.moeraudio.com

Part No:620010610